



Connecting an FM system to the classroom white board.

Standard white board connection

If the whiteboard speakers are plugged into the headphone socket of the laptop / PC then a splitter can be used. Unplug the white board speakers, insert the splitter into the headphone socket, then plug in the speakers back in and connect the Soundfield audio input.



Interactive screens with HDMI digital connection OPTION ONE



Some newer interactive screens use a HDMI connector. This also carries the audio to the screen and isolates the headphone socket on the laptop. The screen often will give you a headphone socket or audio output (seen to the left). Simply use an audio lead from the screen and connect to the JUNO audio input.



Connecting an FM system to the classroom white board.

Interactive screens with HDMI digital connection OPTION TWO

Some interactive screens will sometimes give you a headphone socket out or no audio output at all. The HDMI lead (the main lead from the laptop to screen) can be used to supply audio using a "Audio extractor" as seen below.

