



Rebroadcasting from Frontrow Pro Digital to DM10

Prioryfield House, 20 Canon Street, Taunton, Somerset,
 TA1 1SW, 01823 323363 / 07941015282,
 info@robertsaudiosolutions.co.uk,
 www.robertsaudiosolutions.co.uk



Teachers Microphone



Charger Cable

Cable for Radio Aid

Input for external sound source

Charging socket

Mute Button

Indicator:

Solid Green = Microphone Active

Flashing Green = Microphone Muted

Flashing Red = Battery low

ON/OFF Button